

REVEGO

**Pocket systems for
new space concepts**

Ordering and planning information



Contents

 GERMAN DESIGN AWARD WINNER 2022	 reddot winner 2022	 DESIGN AWARD 2022		10 Overview of product range
				12 Planning approach and product selection
				14 REVEGO uno, single door
				24 REVEGO uno + uno Two single doors combined
				34 REVEGO duo, double door
				46 REVEGO uno + duo, single door and double door combined
				64 REVEGO duo + duo, two double doors combined
				76 Calculations and assembly of the profiles
				81 EXPANDO T – for thin fronts
				82 Assembly devices
				83 Testing and inspection regulations




Efficient manufacturing

REVEGO comes with all essential components thanks to the unique pocket construction with fully integrated fittings. You can easily pre-assemble pocket systems in your workshop or premises and transport them to end users in a carefully packaged state. This makes installation on site easier and increases efficiency.



Get a life-like experience of REVEGO.
Download the AR application and get started:
www.blum.com/rev3



Easy planning

Standardised pocket widths of 100 mm for REVEGO uno single door and 150 mm for REVEGO duo double door give you the freedom to design the furniture around the pocket exactly as you wish. Single and double door applications can be individually combined.



The ultimate in convenience

No need for handles thanks to TIP-ON motion technology; users can open cabinet doors with a single touch and slide them away completely into the pocket. To close off the space, the user simply presses the door to release it from the pocket and then presses it again to elegantly conceal the entire area.

Rapid on-site installation

Final assembly on site is simplicity itself: set up, align and mount the pockets; install the doors and track; make adjustments to the gap layout – and that's it! The 3-dimensional adjustment options are easily accessible and intuitive to use. And thanks to the integrated service interface, it is really simple to remove the fittings – even from built-in furniture.



REVEGO at a glance

- Fast and easy installation thanks to pre-mounted fittings
- Unique pocket construction with fully integrated technology
- Easy planning thanks to predefined pocket widths
- Enhanced ease and mesmerising motion
- Individual design possibilities through the combination of REVEGO uno (1) and REVEGO duo (2)
- Different nominal lengths allow you to adapt applications to the installation situation
- Smooth opening and closing without a handle thanks to integrated TIP-ON motion technology
- Can be designed with or without plinth option or as a worktop-mounted cabinet
- Precise and easily accessible 3-dimensional adjustment options
- Full overlay fronts completely conceal the pocket when closed for a perfect gap layout
- Pocket systems can be used in all living areas
- Suitable for systems to conceal runs of cabinets or walk-in solutions such as dressing rooms or pantries, etc.
- Fittings can be easily removed (even from built-in furniture) thanks to an integrated service interface



Use REVEGO uno single doors on their own, or combine them with REVEGO duo double doors as desired. The full overlay fronts with a height of up to 2980 mm conceal the pocket completely when closed.



It is easy to implement solutions with internal cabinetry or walk-in solutions such as dressing rooms or pantries.



From a front height of 1130 mm, REVEGO can also be implemented as a worktop-mounted cabinet.

Easy product selection

Our Product Configurator makes it easy for you to choose your products and provides checked parts lists, planning information and CAD data.



Our services at a glance

Our services support you every step of the way – from planning and design through to manufacturing and assembly. Take advantage of our tried-and-tested and user-friendly services for your projects with REVEGO.

**Concept, planning and product selection**

Our Product Configurator will help you select the right products quickly and efficiently. It gives you checked parts lists and planning information, as well as accurate production drawings.

**Design**

You can export REVEGO projects in various CAD formats for use in your own design software. Together with selected partners, we have also established interfaces for the straightforward transfer of data and completion of your project in your design software.

**Ordering**

Simply transfer your parts lists from the Product Configurator directly to the web shop of selected distributors. Your REVEGO configurations are easily saved to "My projects", where you can then manage your customer projects.

**Manufacturing**

Speed up your production process with our Product Configurator. Transfer the planning results to MINIPRESS top with EASYSTICK (using BXF) or directly to your CNC machine. In order to transfer the data to your CNC machine, you'll receive specially prepared CAM data (CAM DXF or complete WOP drilling programs) in the Product Configurator. This makes production processes on the CNC machine even quicker and easier.



Find out more about our digital services:
www.blum.com/pcfg1



Register now free of charge to take advantage of the digital services.
www.blum.com/esvs1

Overview of applications and planning notes**REVEGO uno – single door right or left**

Page 14

- Number of fronts: 1
- Installation width: 450 to 900 mm
- Internal width within the application: 350 to 800 mm
- Front width: 442–898 mm

Overview of applications and planning notes**REVEGO uno + duo – single door and double door combined**

Page 46

- Number of fronts: 3
- Installation width: 1350 to 2400 mm
- Internal width within the application: 1100 to 2150 mm
- Front width: 442–748 mm and 442–898 mm

REVEGO uno + uno – two single doors combined

Page 24

- Number of fronts: 2
- Installation width: 900 to 1800 mm
- Internal width within the application: 700 to 1600 mm
- Front width: 442–898 mm

REVEGO duo + duo – two double doors combined

Page 64

- Number of fronts: 4
- Installation width: 1800 to 3000 mm
- Internal width within the application: 1500 to 2700 mm
- Front width: 442–748 mm

REVEGO duo – double door right or left



Page 34

- Number of fronts: 2
- Installation width: 900 to 1500 mm
- Internal width within the application: 750 to 1350 mm
- Front width: 442–748 mm



Watch assembly video:
www.blum.com/rev2

Planning approach and product selection



EB Installation width
LWA Internal width within the application
FB Front width

Niche installation

Planning approach from outside moving inward with fixed installation width EB for the entire application. The space available determines the installation width EB and is the decisive factor for the number of fronts, front widths FB and thus for the choice of application. The fittings and cabinet dimensions within the application can be determined in the next step.

1.	What recess width is available for the application?	2.	Determine the possible number of fronts and front widths FB based on the installation width EB.	3.	The pocket dimensions, front protrusion FU and internal dimensions can now be defined on the planning pages of the respective application, and additional fittings can be selected.
	The recess width is the installation width EB for the application.		This will determine the type of application.		

Free-standing installation

Planning approach from the inside moving outward with focus on the cabinet width KB and cabinetry within the application. The cabinetry to be concealed is the decisive factor for the potential number of fronts, front widths FB and thus for the choice of application. The installation dimensions and fittings are determined in the next step.

1.	What is the cabinet width KB that needs to be concealed?	2.	Determine the possible number of fronts and front widths FB based on the internal width within the application LWA.	3.	The pocket dimensions and front protrusion FU can now be defined on the planning pages of the respective application, and additional fittings can be selected.
	The cabinet width KB is the internal width within the application LWA.		This will determine the type of application and its installation width EB.		

Front width FB and number of fronts


Planning approach with pre-defined front widths FB and number of fronts. The pre-defined front width FB and the number of fronts determine the choice of application and are the decisive factor for the installation width of the entire application. The fittings and cabinet dimensions within the application can be determined in the next step.

1.	What front width FB and what number of fronts were selected?	2.	The type of application and desired front width FB plus the side gaps determine the installation width.	3.	The pocket dimensions, front protrusion FU and internal dimensions can now be defined on the planning pages of the respective application, and additional fittings can be selected.
	The number of fronts defines the type of application.				


Planning approach and product selection

Min. distance

REVEGO uno



REVEGO duo



A minimum distance to the nearest element in front of the pocket must be kept free for safety reasons!


FB + min. 300 mm

FB Front width

POT Pocket depth

Front protrusion FU

The minimum front protrusion results from the combination of nominal length, front width and the TIP-ON trigger path (AW) when using standard nominal lengths (pocket profile set with TIP-ON). By cutting the profiles to size, the front protrusion (FU) can be customised (min. FU = 7 mm).



FU = FB + AW - NL


AW TIP-ON trigger path

FB Front width

FU Front protrusion

NL Nominal length

Example



NL Nominal length

PORW Pocket back

POT Pocket depth

Note

- The internal dimensions within the application (internal width | internal height | internal depth) define the maximum space available for internal cabinetry
- Design the widest front first for combined applications
- The manual operating force is less than 70 N according to the durability test
- Drilling patterns, cut-to-size dimensions and detailed parts lists can be found in the Product Configurator

Assembly

- You will need a CNC machine or MINIPRESS top with EASYSTICK from Blum to machine the wooden parts
- Please note that both horizontal drillings and additional wood machining (e.g. a track cut-out) will be needed
- We recommend using the drilling template for REVEGO for the horizontal drillings
- See appendix for calculation and assembly information for cutting profiles to size



For more safety information, please go to:
www.blum.com/rev4


REVEGO uno – single door right or left



Space requirement

Installation dimensions (mm)	Installation width EB	Installation height EH	Installation depth ET
450–900	1155–3012	from 573	
Internal dimensions within the application (mm)	Internal width within the application LWA	Internal height within the application LHA	Internal depth within the application LTA
up to 800	up to 2999	from 518	
Pocket dimensions (mm)	Pocket width POB	Pocket height POH	Pocket depth POT
100	1142–2999	from 553	
Front dimensions (mm)	Front width FB	Front height FH	Front thickness FD
442–898	1130–2980	18–26	
Front weight FG	up to 35 kg per front		

Overview



Fittings selection made easy

It is easy to work out the fittings and drilling positions you need using the Product Configurator.

With every product configuration, you will receive manufacturing drawings, cutting lists for wooden parts and fittings, 3D CAD data for your design software, as well as CAM programs including drilling information for direct machining on your CNC machine, in addition to the checked parts list.

Enter the web code in the Product Configurator, click on the short URL or scan the QR code. Don't have login information for digital services yet? Register here and get access free of charge.

Web code




Product Configurator
www.blum.com/rev8



Assembly and adjustment
www.blum.com/rev5

Component overview

Pocket




Consisting of:

1a	Top pocket profile
1b	Bottom pocket profile
1d	TIP-ON unit pocket
1e	Fixing clips
1f	BLUMOTION unit pocket
1g	Attachment for pocket cover strip
1h	BLUMATIC unit
2f	Hinge bracket
2i	Pocket cover strip
2l	Mounting for pocket cover strip
3a/4a/5a	Front pocket connector
3b/4b/5b	Rear pocket connector
Z	Scuff guard
POAS	External pocket side
POIS	Internal pocket side
PORW	Pocket back

Component overview

Front



Consisting of:

1i	Door stabiliser
2a	Hinge strip
2g	TIP-ON spacer
2h	TIP-ON incl. catch plate

A We recommend at least one alignment fitting with a maximum installation height of 3 mm.

Alignment fittings with a height of more than 3 mm must not be used in the pocket.

Ordering information

1

Pocket profile set with TIP-ON

	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right
	450	550	801P450E.L3	801P450E.R3
	500	600	801P500E.L3	801P500E.R3
	600	700	801P600E.L3	801P600E.R3
	700	800	801P700E.L3	801P700E.R3
	800	900	801P800E.L3	801P800E.R3

* Specification without pocket back. A back construction with a thickness of at least 3 mm is required.
Pocket profiles and TIP-ON unit pocket can be shortened to any nominal length.

Consisting of:

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1d	1 x	TIP-ON unit pocket
1e	5 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip
1h	1 x	BLUMATIC unit
1i	2 x	Door stabiliser: runner profile incl. end cap, black anodised

2

Hinge bracket set

	Pocket height (mm)	Left	Right
	1142-1356	801T1140.L3	801T1140.R3
	1357-1506	801T1350.L3	801T1350.R3
	1507-1656	801T1500.L3	801T1500.R3
	1657-1806	801T1650.L3	801T1650.R3
	1807-1956	801T1800.L3	801T1800.R3
	1957-2106	801T1950.L3	801T1950.R3
	2107-2256	801T2100.L3	801T2100.R3
	2257-2406	801T2250.L3	801T2250.R3
	2407-2556	801T2400.L3	801T2400.R3
	2557-2706	801T2550.L3	801T2550.R3
	2707-2856	801T2700.L3	801T2700.R3
	2857-2999	801T2850.L3	801T2850.R3

Cover strips must be shortened to the required length

Consisting of:

2a	1 x	Hinge strip, black
2f	1 x	Hinge bracket
2g	1 x	TIP-ON spacer
2h	1 x	TIP-ON incl. catch plate, black
2i	1 x	Pocket cover strip, black anodised
2l	3-5 x	Mountings for pocket cover strip
-	21 x	System screws for 1i, 2a and 2g, 6 x 14.5 mm, black

Ordering information**Pocket connector set****3 Application with plinth**

Pocket side thickness (mm)		Colour	
15-19		Black	801V505B

Pocket connector top + bottom: POVH 10 mm for 0-6 mm gap

POVH Pocket connector height

Consisting of:

3a	2 x	Front pocket connector
3b	2 x	Rear pocket connector

Pocket connector set**4 Application without plinth**

Pocket side thickness (mm)		Colour	Left	Right
15-19		Black	801V605B.L1	801V605B.R1

Top pocket connector: POVH 10 mm for 0-6 mm gap

Bottom pocket connector: POVH 3 mm for gap from 7-13 mm

POVH Pocket connector height

Consisting of:

4a	2 x	Front pocket connector
4b	2 x	Rear pocket connector

Pocket connector set**5 Worktop-mounted cabinet application**

Pocket side thickness (mm)		Colour	Left	Right
15-19		Black	801V705B.L3	801V705B.R3

Top pocket connector: POVH 10 mm for 0-6 mm gap

Bottom pocket connector: POVH 3 mm for gap from 3-6 mm

POVH Pocket connector height

Consisting of:

5a	2 x	Front pocket connector
5b	2 x	Rear pocket connector

Ordering information**Z Accessories****Scuff guard**

	For front thicknesses starting from 23 mm	801ZA00S
	For front thicknesses less than 23 mm, the scuff guard can be used as additional front protection	

Consisting of:

3 x	External pocket side scuff guard (POAS)
-----	---

Screws

	6 x 14.5 mm system screws, nickel plated	661.1450.HG
---	--	-------------

Pocket connector

	Rear pocket connector, pocket connector height (POVH) 10 mm	801V5002
---	---	----------

Additional pocket connector for set-back plinth leg

EXPANDO T – for thin fronts


	EXPANDO T – single	70T4532T
--	--------------------	----------

EXPANDO T suitable for thin fronts – see page 81


For front thicknesses less than 18 mm, we recommend a trial application


Screws are not included in the scope of delivery

Planning



Planning




Planning**Installation height, front height****Application without plinth**

FH = POH - Fo - Fu
 EH = POH + POVH top and bottom
 POVH top 10 mm: gap 0–6 mm
 POVH bottom 3 mm: gap from 7–13 mm

- Take into account that the pocket must be tilted during installation.
- Minimum distance from the bottom front edge to the floor or next element below is 10 mm
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- The pocket connector height must be taken into account during planning

EH Installation height
 Fo Top gap
 Fu Bottom gap
 FH Front height
 POH Pocket height
 POVH Pocket connector height

Installation height, front height**Worktop-mounted cabinet application**

FH = POH - Fo - Fu
 EH = POH + POVH top and bottom
 POVH top 10 mm: gap 0–6 mm
 POVH bottom 3 mm: gap from 3–6 mm

- Take into account that the pocket must be tilted during installation.
- The minimum distance between the front and the next element below with a flush front (e.g. worktop is not visible) is 3 mm
- The minimum distance between the front and the next element below with a protruding element (e.g. worktop is visible) is 6 mm
- The minimum distance to the next movable element above is 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- A trial application is recommended in the edge areas
- The pocket connector height must be taken into account during planning
- The distance between the front and the next element above and below is made up of Fu or Fo + POVH

EH Installation height
 Fo Top gap
 Fu Bottom gap
 FH Front height
 POH Pocket height
 POVH Pocket connector height


* If the distance between the front and the next element below is < 6 mm, the pocket connector must be embedded in the worktop

Planning**Max. front weights for worktop-mounted cabinets in kg per front**

Front height FH (mm)	Front width FB (mm)						
	450	500	550	600	650	700	750
1130 - 1349	22	20	18	16	15	14	13
1350–1499	23	21	19	18	17	16	15
1500–1649	25	23	21	19	18	17	16
1650–1799	27	25	23	21	20	19	18

Note

- The max. front width when planning a worktop-mounted cabinet is 750 mm
- The max. pocket height when planning a worktop-mounted cabinet is 1806 mm

Internal height and internal depth within the application

LHA	Internal height within the application
LTA	Internal depth within the application
POH	Pocket height
POT	Pocket depth


REVEGO uno + uno – single door right and single door left



Space requirement

Installation dimensions (mm)	Installation width EB	Installation height EH	Installation depth ET
900–1800	1155–3012	from 573	
Internal dimensions within the application (mm)	Internal width within the application LWA	Internal height within the application LHA	Internal depth within the application LTA
up to 1600	up to 2999	from 518	
Pocket dimensions (mm)	Pocket width POB	Pocket height POH	Pocket depth POT
100	1142–2999	from 553	
Front dimensions (mm)	Front width FB	Front height FH	Front thickness FD
442–898	1130–2980	18–26	
Front weight FG	up to 35 kg per front		

Overview



Fittings selection made easy

It is easy to work out the fittings and drilling positions you need using the Product Configurator.

With every product configuration, you will receive manufacturing drawings, cutting lists for wooden parts and fittings, 3D CAD data for your design software, as well as CAM programs including drilling information for direct machining on your CNC machine, in addition to the checked parts list.

Enter the web code in the Product Configurator, click on the short URL or scan the QR code. Don't have login information for digital services yet? Register here and get access free of charge.

Web code

DQDN1C




Product Configurator
www.blum.com/rev9



Assembly and adjustment
www.blum.com/rev5

Component overview

Pocket




Consisting of:

1a	Top pocket profile
1b	Bottom pocket profile
1d	TIP-ON unit pocket
1e	Fixing clips
1f	BLUMOTION unit pocket
1g	Attachment for pocket cover strip
1h	BLUMATIC unit
2f	Hinge bracket
2i	Pocket cover strip
2l	Mounting for pocket cover strip
3a/4a/5a	Front pocket connector
3b/4b/5b	Rear pocket connector
Z	Scuff guard
POAS	External pocket side
POIS	Internal pocket side
PORW	Pocket back

Component overview

Front



Consisting of:

1i	Door stabiliser
2a	Hinge strip
2g	TIP-ON spacer
2h	TIP-ON incl. catch plate
10	Inter-door support

A We recommend at least one alignment fitting with a maximum installation height of 3 mm.
Alignment fittings with a height of more than 3 mm must not be used in the pocket.

Ordering information

1 Pocket profile set with TIP-ON

	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right
	450	550	801P450E.L3	801P450E.R3
	500	600	801P500E.L3	801P500E.R3
	600	700	801P600E.L3	801P600E.R3
	700	800	801P700E.L3	801P700E.R3
	800	900	801P800E.L3	801P800E.R3

* Specification without pocket back. A back construction with a thickness of at least 3 mm is required.
Pocket profiles and TIP-ON unit pocket can be shortened to any nominal length.

Consisting of:

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1d	1 x	TIP-ON unit pocket
1e	5 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip
1h	1 x	BLUMATIC unit
1i	2 x	Door stabiliser: runner profile incl. end cap, black anodised

Order set for each single door, 1x left and 1x right

2 Hinge bracket set

	Pocket height (mm)	Left	Right
	1142-1356	801T1140.L3	801T1140.R3
	1357-1506	801T1350.L3	801T1350.R3
	1507-1656	801T1500.L3	801T1500.R3
	1657-1806	801T1650.L3	801T1650.R3
	1807-1956	801T1800.L3	801T1800.R3
	1957-2106	801T1950.L3	801T1950.R3
	2107-2256	801T2100.L3	801T2100.R3
	2257-2406	801T2250.L3	801T2250.R3
	2407-2556	801T2400.L3	801T2400.R3
	2557-2706	801T2550.L3	801T2550.R3
	2707-2856	801T2700.L3	801T2700.R3
	2857-2999	801T2850.L3	801T2850.R3

Cover strips must be shortened to the required length

Consisting of:

2a	1 x	Hinge strip, black
2f	1 x	Hinge bracket
2g	1 x	TIP-ON spacer
2h	1 x	TIP-ON incl. catch plate, black
2i	1 x	Pocket cover strip, black anodised
2l	3-5 x	Mountings for pocket cover strip
-	21 x	System screws for 1i, 2a, 2g and 10, 6 x 14.5 mm, black

Order set for each single door, 1x left and 1x right

Pocket connector set			
3	Application with plinth		
	Pocket side thickness (mm)	Colour	
15–19	Black		801V505B
Pocket connector top + bottom: POVH 10 mm for 0–6 mm gap			
POVH Pocket connector height			
Consisting of:			
3a	2 x	Front pocket connector	
3b	2 x	Rear pocket connector	
Order 1x per single door			

Pocket connector set				
4	Application without plinth			
	Pocket side thickness (mm)	Colour	Left	Right
15–19	Black	801V605B.L1	801V605B.R1	
Top pocket connector: POVH 10 mm for 0–6 mm gap				
Bottom pocket connector: POVH 3 mm for gap from 7–13 mm				
POVH Pocket connector height				
Consisting of:				
4a	2 x	Front pocket connector		
4b	2 x	Rear pocket connector		
Order set for each single door, 1x left and 1x right				


Pocket connector set				
5	Worktop-mounted cabinet application			
	Pocket side thickness (mm)	Colour	Left	Right
15–19	Black	801V705B.L3	801V705B.R3	
Top pocket connector: POVH 10 mm for 0–6 mm gap				
Bottom pocket connector: POVH 3 mm for gap from 3–6 mm				
POVH Pocket connector height				
Consisting of:				
5a	2 x	Front pocket connector		
5b	2 x	Rear pocket connector		
Order set for each single door, 1x left and 1x right				

10 Assembly set for two single doors combined			
	Colour		
	Black		800ZA02S
Consisting of:			
1 x	Inter-door support (right + left)		

Ordering information

Z	Accessories	
Scuff guard		
	For front thicknesses starting from 23 mm	801ZA00S
	For front thicknesses less than 23 mm, the scuff guard can be used as additional front protection	
Consisting of:		
3 x	External pocket side scuff guard	
Screws		
	6 x 14.5 mm system screws, nickel plated	661.1450.HG
Pocket connector		
	Rear pocket connector, pocket connector height (POVH) 10 mm	801V5002
Additional pocket connector for set-back plinth leg		
EXPANDO T – for thin fronts		
	EXPANDO T – single	70T4532T
EXPANDO T suitable for thin fronts – see page 81		
For front thicknesses less than 18 mm, we recommend a trial application		
Screws are not included in the scope of delivery		

Planning



Installation depth/pocket depth

$$ET = POT + FS (2 \text{ mm}) + FD$$

$$\text{Min. POT} = NL + POTV (\geq 100 \text{ mm}) + PORW (\geq 3 \text{ mm})$$

Installation width/internal width within the application

$$EB = 2 \times LWA1 + 2 \times POB (100 + 100 \text{ mm})$$

$$FB = EB - FSl - Fsr$$

$$FSl/Fsr = 1.0-4.0 \text{ mm}; Fsm = 2.0-8.0 \text{ mm}$$

$$FD = 18-26 \text{ mm}$$

$$\text{Max. NL} = FB + 8 \text{ mm}$$

$$FU = FB - NL + 15 \text{ mm}$$

(min. FU = 7 mm)

$$FD = 18-26 \text{ mm}$$

- By cutting the profiles to size, the front protrusion (FU) can be customised.
- To ensure optimum functionality, the fronts are at a slight angle inside the pocket.
- A partition side is required for a stand-alone application, or one adjacent to a worktop area.
- The internal width within the application determines the maximum width available for the internal cabinetry.
- For front thicknesses (FD) less than 18 mm (possible depending on material/stability), we recommend a trial application.

EB Installation width

ET Installation depth

FSl Gap left

Fsr Gap right

Fsm Centre side gap
(between the fronts)

FB Front width

FD Front thickness

FS Front gap

FU Front protrusion

LWA Internal width within the application

LWA1 Internal width within the application,
single door

NL Nominal length

POB Pocket width

POT Pocket depth

PORs Pocket back cut

PORW Pocket back


POSD Pocket side thickness

POTV Pocket depth loss


Planning

Minimum side gap

Pocket to pocket/adjacent cabinet



Pocket to wall/decor panel




FD (mm)	Min. Fs (mm)
18-20	2
20.1-23	2.5
23.1-26	3

FD Front thickness
Fs Side gap

Installation height, front height

Application with plinth



$$FH = POH - Fo - Fu$$

$$EH = POH + POVH \text{ top and bottom}$$

$$POVH 10 \text{ mm: gap } 0-6 \text{ mm}$$

- Take into account that the pocket must be tilted during installation.
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- The pocket connector height must be taken into account during planning
- Minimum plinth height 80 mm

EH Installation height

Fo Top gap

Fu Bottom gap


FH Front height


POH Pocket height

POVH Pocket connector height

Application with set-back plinth

Additional rear pocket connector




Planning**Installation height, front height****Application without plinth**

FH = POH - Fo - Fu
 EH = POH + POVH top and bottom
 POVH top 10 mm: gap 0–6 mm
 POVH bottom 3 mm: gap from 7–13 mm

- Take into account that the pocket must be tilted during installation.
- Minimum distance from the bottom front edge to the floor or next element below is 10 mm
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- The pocket connector height must be taken into account during planning

EH Installation height
 Fo Top gap
 Fu Bottom gap
 FH Front height
 POH Pocket height
 POVH Pocket connector height

Installation height, front height**Worktop-mounted cabinet application**

FH = POH - Fo - Fu
 EH = POH + POVH top and bottom
 POVH top 10 mm: gap 0–6 mm
 POVH bottom 3 mm: gap from 3–6 mm

- Take into account that the pocket must be tilted during installation.
- The minimum distance between the front and the next element below with a flush front (e.g. worktop is not visible) is 3 mm
- The minimum distance between the front and the next element below with a protruding element (e.g. worktop is visible) is 6 mm
- The minimum distance to the next movable element above is 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- A trial application is recommended in the edge areas
- The pocket connector height must be taken into account during planning
- The distance between the front and the next element above and below is made up of Fu or Fo + POVH

EH Installation height
 Fo Top gap
 Fu Bottom gap
 FH Front height
 POH Pocket height
 POVH Pocket connector height


* If the distance between the front and the next element below is < 6 mm, the pocket connector must be embedded in the worktop

Planning**Max. front weights for worktop-mounted cabinets in kg per front**

Front height FH (mm)	Front width FB (mm)						
	450	500	550	600	650	700	750
1130 - 1349	22	20	18	16	15	14	13
1350–1499	23	21	19	18	17	16	15
1500–1649	25	23	21	19	18	17	16
1650–1799	27	25	23	21	20	19	18

Note


- The max. front width when planning a worktop-mounted cabinet is 750 mm
- The max. pocket height when planning a worktop-mounted cabinet is 1806 mm

Internal height and internal depth within the application

LHA = POH
 LTA = POT - 35 mm

- The internal height/internal depth within the application determines the maximum height/depth available for the internal cabinetry.

LHA Internal height within the application
 LTA Internal depth within the application
 POH Pocket height
 POT Pocket depth

Inter-door support

- Supports a single door against a double door, two single doors against each other or two double doors against each other

P Pocket


REVEGO duo – double door right or left



Space requirement

Installation dimensions (mm)	Installation width EB	Installation height EH	Installation depth ET
	900–1500	1155–3012	from 573
Internal dimensions within the application (mm)	Internal width within the application LWA	Internal height within the application LHA	Internal depth within the application LTA
	up to 1350	up to 2884	from 483
Pocket dimensions (mm)	Pocket width POB	Pocket height POH	Pocket depth POT
	150	1142–2999	from 553
Front dimensions (mm)	Front width FB	Front height FH	Front thickness FD
	442–748	1130–2980	18–26
Front weight FG	up to 35 kg per front		

Overview



Fittings selection made easy

It is easy to work out the fittings and drilling positions you need using the Product Configurator.

With every product configuration, you will receive manufacturing drawings, cutting lists for wooden parts and fittings, 3D CAD data for your design software, as well as CAM programs including drilling information for direct machining on your CNC machine, in addition to the checked parts list.

Enter the web code in the Product Configurator, click on the short URL or scan the QR code. Don't have login information for digital services yet? Register here and get access free of charge.

Web code




Product Configurator
www.blum.com/rev10



Assembly and adjustment
www.blum.com/rev6

Component overview

Pocket




Consisting of:

- 1a Top pocket profile
- 1b Bottom pocket profile
- 1c Roller profile
- 1d TIP-ON unit pocket
- 1e Fixing clips
- 1f BLUMOTION unit pocket
- 1g Attachment for pocket cover strip
- 2f Hinge bracket
- 2i Pocket cover strip
- 2l Mounting for pocket cover strip
- 2m Pocket cover strip support
- 3a/4a/5a Front pocket connector
- 3b/4b/5b Rear pocket connector
- Z Scuff guard
- POAS External pocket side
- POIS Internal pocket side
- PORW Pocket back

Component overview

Front



Consisting of:


2a	Hinge strip
2b	Centre hinge
2c	Roller carriage hinge
2d	TIP-ON unit door
2e	Support for door cover strip
2j	Door cover strip
2k	Mounting for door cover strip
7e	Door support for decor panel/cabinet side

A We recommend at least one alignment fitting per front with a maximum installation height of 20 mm.

The space available between the pair of folding fronts is 20 mm.

Component overview

Track



Consisting of:

2i	Pocket cover strip
6a	Track
6b	Roller carriage
6c	Roller carriage transporter
6d	Mounting for track cover panel
6e	Catch plate
6f	Spacer
7a	Track fixing
7b	Cover for track fixing
7c	Pin for track fixing
7d	Door support on partition side
7e	Door support for decor panel/cabinet side
SS	Optional partition side
ZB	Fixed shelf
LTB	Track cover panel

Ordering information

1	Pocket profile set with TIP-ON			
	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right
450	550		802P450D.L3	802P450D.R3
525	625		802P525D.L3	802P525D.R3
600	700		802P600D.L3	802P600D.R3
675	775		802P675D.L3	802P675D.R3
750	850		802P750D.L3	802P750D.R3

* Specification without pocket back. A back construction with a thickness of at least 3 mm is required.

Pocket and roller profiles as well as TIP-ON unit pocket can be shortened to any nominal length.

Consisting of:

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1c	1 x	Roller profile
1d	1 x	TIP-ON unit pocket
1e	6 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip

2	Hinge bracket set with TIP-ON			
	Pocket height (mm)	Left	Right	
	1142-1356	802T1140.L3	802T1140.R3	
	1357-1506	802T1350.L3	802T1350.R3	
	1507-1656	802T1500.L3	802T1500.R3	
	1657-1806	802T1650.L3	802T1650.R3	
	1807-1956	802T1800.L3	802T1800.R3	
	1957-2106	802T1950.L3	802T1950.R3	
	2107-2256	802T2100.L3	802T2100.R3	
	2257-2406	802T2250.L3	802T2250.R3	
	2407-2556	802T2400.L3	802T2400.R3	
	2557-2706	802T2550.L3	802T2550.R3	
	2707-2856	802T2700.L3	802T2700.R3	
	2857-2999	802T2850.L3	802T2850.R3	

Cover strips must be shortened to the required length

Consisting of:

2a	1 x	Hinge strip
2b	5 x	Centre hinge
2c	1 x	Roller carriage hinge
2d	1 x	TIP-ON unit door
2e	1 x	Support for door cover strip
2f	1 x	Hinge bracket
2i	1 x	Pocket cover strip, black anodised
2j	1 x	Door cover strip, black anodised
2k	4 x	Mounting for door cover strip
2l	2-5 x	Mountings for pocket cover strip
2m	1 x	Pocket cover strip support


Ordering information



Pocket connector set				
3	Application with plinth			
		Pocket side thickness (mm)	Colour	
		15-17	Black	802V560B
		18-19	Black	802V580B
Pocket connector top + bottom: POVH 10 mm for 0-6 mm gap				
POVH Pocket connector height				
Consisting of:				
3a	2 x	Front pocket connector		
3b	2 x	Rear pocket connector		
Pocket connector set				
4	Application without plinth			
		Pocket side thickness (mm)	Colour	Left
		15-17	Black	802V660B.L1
		18-19	Black	802V680B.L1
Top pocket connector: POVH 10 mm for 0-6 mm gap				
Bottom pocket connector: POVH 3 mm for gap from 7-13 mm				
POVH Pocket connector height				
Consisting of:				
4a	2 x	Front pocket connector		
4b	2 x	Rear pocket connector		
Pocket connector set				
5	Worktop-mounted cabinet application			
		Pocket side thickness (mm)	Colour	Left
		15-17	Black	802V760B.L3
		18-19	Black	802V780B.L3
Top pocket connector: POVH 10 mm for 0-6 mm gap				
Bottom pocket connector: POVH 3 mm for gap from 3-6 mm				
POVH Pocket connector height				
Consisting of:				
5a	2 x	Front pocket connector		
5b	2 x	Rear pocket connector		
Track set				
6	LWA double door (mm)			
		Colour	Left	Right
	1050	Black anodised	802L1050DL3	802L1050DR3
	1200	Black anodised	802L1200DL3	802L1200DR3
	1250	Black anodised	802L1250DL3	802L1250DR3
	1350	Black anodised	802L1350DL3	802L1350DR3
Track can be shortened to any length.				
LWA Internal width within the application				
Consisting of:				
6a	1 x	Track		
6b	1 x	Roller carriage		
6c	1 x	Roller carriage transporter		
6d	2 x	Mounting for track cover panels		
6e	1 x	Catch plate, black		
6f	2 x	Spacer		

Ordering information

7	Assembly set for one double door	
	Colour	Left Right
Black		
	802M0002.L2 802M0002.R2	
Consisting of:		
7a	1 x	Track fixing
7b	1 x	Cover for track fixing
7c	2 x	Pin for track fixing
7d	1 x	Door support on partition side (can be selected depending on installation situation)
7e	1 x	Door support for decor panel/cabinet side incl. attachment (can be selected depending on installation situation)
Z	Accessories	
Scuff guard		
	For front thicknesses starting from 23 mm	802ZA00S
	For front thicknesses less than 23 mm, the scuff guard can be used as additional front protection	
Consisting of:		
3 x	External pocket side scuff guard	
2 x	Internal pocket side scuff guard	
Screws		
	6 x 14.5 mm system screws, nickel plated	661.1450.HG
Pocket connector		
	Rear pocket connector, pocket connector height (POVH) 10 mm	802V5002
	Additional pocket connector for set-back plinth leg	
EXPANDO T – for thin fronts		
	EXPANDO T – single	70T4532T
	EXPANDO T suitable for thin fronts – see page 81	
	For front thicknesses less than 18 mm, we recommend a trial application	
	Screws are not included in the scope of delivery	

Planning




Planning**Minimum side gap****Pocket to pocket/adjacent cabinet****Pocket to wall/decor panel**

FD (mm)	Min. Fs (mm)
18–20	2
20.1–23	2.5
23.1–26	3

FD Front thickness

Fs Side gap

Installation height, front height**Application with plinth**

FH = POH - Fo - Fu

EH = POH + POVH top and bottom

POVH 10 mm: gap 0–6 mm

- Take into account that the pocket must be tilted during installation.
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- The pocket connector height must be taken into account during planning
- Minimum plinth height 80 mm

EH Installation height



Fo Top gap

Fu Bottom gap

FH Front height

POH Pocket height

POVH Pocket connector height

Application with set-back plinth**Additional rear pocket connector****Planning****Installation height, front height****Application without plinth**

FH = POH - Fo - Fu

EH = POH + POVH top and bottom

POVH top 10 mm: gap 0–6 mm

POVH bottom 3 mm: gap from 7–13 mm

- Take into account that the pocket must be tilted during installation.
- Minimum distance from the bottom front edge to the floor or next element below is 10 mm
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- The pocket connector height must be taken into account during planning

EH Installation height


Fo Top gap

Fu Bottom gap

FH Front height

POH Pocket height

POVH Pocket connector height

Installation height, front height**Worktop-mounted cabinet application**

FH = POH - Fo - Fu

EH = POH + POVH top and bottom

POVH top 10 mm: gap 0–6 mm

POVH bottom 3 mm: gap from 3–6 mm

- Take into account that the pocket must be tilted during installation.
- The minimum distance between the front and the next element below with a flush front (e.g. worktop is not visible) is 3 mm
- The minimum distance between the front and the next element below with a protruding element (e.g. worktop is visible) is 6 mm
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- A trial application is recommended in the edge areas
- The pocket connector height must be taken into account during planning
- The distance between the front and the next element above and below is made up of Fu or Fo + POVH

EH Installation height

Fo Top gap

Fu Bottom gap

FH Front height

POH Pocket height


POVH Pocket connector height

Planning**Max. front weights for worktop-mounted cabinets in kg per front**

Front height FH (mm)	Front width FB (mm)						
	450	500	550	600	650	700	750
1130 - 1349	22	20	18	16	15	14	13
1350-1499	23	21	19	18	17	16	15
1500-1649	25	23	21	19	18	17	16
1650-1799	27	25	23	21	20	19	18


Note

- The max. pocket height when planning a worktop-mounted cabinet is 1806 mm

Door support on partition side


- Assembly height of the door support ideally as far down as possible, however up to a maximum height of 1000 mm from the front bottom edge
- Ensure collision-free installation

FS Front gap
SS Partition side
7d Door support on partition side

Door support for decor panel/cabinet side

- Installation height AS: 64 mm + Fu from the decor panel/cabinet bottom edge
- Installation height front: 64 mm from the front bottom edge
- Ensure collision-free installation


AS Decor panel/cabinet side
Fu Bottom gap
7e Door support for decor panel/cabinet side

Planning**Track installation dimension**

LBH = 83 mm
LBD = 15-19 mm
(the spacer must be used ≤ 17 mm)
LTF = 17 mm
LA = 100 mm
LV = LA + ZBD (≥ 15 mm)

- We recommend using a cross member to stabilise the fixed shelf.
Minimum distance to front edge of internal pocket side = 170 mm
- A solid connection between the fixed shelf and the pocket with connector fittings is recommended for an attractive gap layout
- No mounting of add-on parts directly on the track

FD Front thickness
LA Track cut-out
LV Track installation
LBD Track cover panel thickness
LBH Track cover panel height
LTF Track gap
PORS Pocket back cut
ZBD Fixed shelf thickness

Internal height and internal depth within the application

LHA = POH - LV
LTA = POT - 70 mm
The internal height/internal depth within the application determines the maximum height/depth available for the internal cabinetry.

LHA Internal height within the application
LTA Internal depth within the application
LV Track installation
POH Pocket height
POT Pocket depth


REVEGO uno + duo – single door right or left and double door right or left



Space requirement

Installation dimensions (mm)	Installation width EB	Installation height EH	Installation depth ET
	1350–2400	1155–3012	from 573
Internal dimensions within the application (mm)	Internal width within the application LWA	Internal height within the application LHA	Internal depth within the application LTA
	up to 2150	up to 2884	from 483
Pocket dimensions (mm)	Pocket width POB	Pocket height POH	Pocket depth POT
	100 / 150	1142–2999	from 553
Front dimensions (mm)	Front width FB	Front height FH	Front thickness FD
	442–898/748	1130–2980	18–26
Front weight FG	up to 35 kg per front		

Overview



Fittings selection made easy

It is easy to work out the fittings and drilling positions you need using the Product Configurator.

With every product configuration, you will receive manufacturing drawings, cutting lists for wooden parts and fittings, 3D CAD data for your design software, as well as CAM programs including drilling information for direct machining on your CNC machine, in addition to the checked parts list.

Enter the web code in the Product Configurator, click on the short URL or scan the QR code. Don't have login information for digital services yet? Register here and get access free of charge.

Web code




Product Configurator
www.blum.com/rev11



Assembly and adjustment
www.blum.com/rev7

Double door component overview

Pocket




Consisting of:

- 1a Top pocket profile
- 1b Bottom pocket profile
- 1c Roller profile
- 1d TIP-ON unit pocket
- 1e Fixing clips
- 1f BLUMOTION unit pocket
- 1g Attachment for pocket cover strip
- 2f Hinge bracket
- 2i Pocket cover strip
- 2l Mounting for pocket cover strip
- 2m Pocket cover strip support
- 3a/4a/5a Front pocket connector
- 3b/4b/5b Rear pocket connector
- Z Scuff guard
- POAS External pocket side
- POIS Internal pocket side
- PORW Pocket back

Double door component overview

Front



Consisting of:


2a	Hinge strip
2b	Centre hinge
2c	Roller carriage hinge
2d	TIP-ON unit door
2e	Support for door cover strip
2j	Door cover strip
2k	Mounting for door cover strip
8i	Inter-door support
Z	Inner door support incl. tip-assist

A We recommend at least one alignment fitting per front with a maximum installation height of 20 mm.

The space available between the pair of folding fronts is 20 mm.

Double door component overview

Track




Consisting of:

2h	TIP-ON incl. catch plate
2i	Pocket cover strip incl. mounting
6a	Track
6b	Roller carriage
6c	Roller carriage transporter
6d	Mounting for track cover panels
6e	Catch plate
6f	Spacer
7a	Track fixing
7b	Cover for track fixing
7c	Pin for track fixing
8a	Track extension
8d	Track connection
8e	Cover for track connection
8f	Support angle for depth adjustment
LTB	Track cover panel
ZB	Fixed shelf

Single door component overview

Pocket




Consisting of:

1a	Top pocket profile
1b	Bottom pocket profile
1d	TIP-ON unit pocket
1e	Fixing clips
1f	BLUMOTION unit pocket
1g	Attachment for pocket cover strip
1h	BLUMATIC unit
2f	Hinge bracket
2i	Pocket cover strip
2l	Mounting for pocket cover strip
3a/4a/5a	Front pocket connector
3b/4b/5b	Rear pocket connector
Z	Scuff guard
POAS	External pocket side
POIS	Internal pocket side
PORW	Pocket back

Single door component overview

Front



Consisting of:

1i	Door stabiliser
2a	Hinge strip
2g	TIP-ON spacer
8i	Inter-door support

A We recommend at least one alignment fitting with a maximum installation height of 3 mm.
Alignment fittings with a height of more than 3 mm must not be used in the pocket.

Double door ordering information

1	Pocket profile set with TIP-ON			
	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right
	450	550	802P450D.L3	802P450D.R3
	525	625	802P525D.L3	802P525D.R3
	600	700	802P600D.L3	802P600D.R3
	675	775	802P675D.L3	802P675D.R3
	750	850	802P750D.L3	802P750D.R3

* Specification without pocket back. A back construction with a thickness of at least 3 mm is required.

Pocket and roller profiles as well as TIP-ON unit pocket can be shortened to any nominal length.

Consisting of:

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1c	1 x	Roller profile
1d	1 x	TIP-ON unit pocket
1e	6 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip

2	Hinge bracket set with TIP-ON			
	Pocket height (mm)	Left	Right	
	1142-1356	802T1140.L3	802T1140.R3	
	1357-1506	802T1350.L3	802T1350.R3	
	1507-1656	802T1500.L3	802T1500.R3	
	1657-1806	802T1650.L3	802T1650.R3	
	1807-1956	802T1800.L3	802T1800.R3	
	1957-2106	802T1950.L3	802T1950.R3	
	2107-2256	802T2100.L3	802T2100.R3	
	2257-2406	802T2250.L3	802T2250.R3	
	2407-2556	802T2400.L3	802T2400.R3	
	2557-2706	802T2550.L3	802T2550.R3	
	2707-2856	802T2700.L3	802T2700.R3	
	2857-2999	802T2850.L3	802T2850.R3	

Cover strips must be shortened to the required length

Consisting of:

2a	1 x	Hinge strip
2b	5 x	Centre hinge
2c	1 x	Roller carriage hinge
2d	1 x	TIP-ON unit door
2e	1 x	Support for door cover strip
2f	1 x	Hinge bracket
2i	1 x	Pocket cover strip, black anodised
2j	1 x	Door cover strip, black anodised
2k	4 x	Mounting for door cover strip
2l	2-5 x	Mountings for pocket cover strip
2m	1 x	Pocket cover strip support

Double door ordering information

Pocket connector set				
3	Application with plinth			
		Pocket side thickness (mm)	Colour	
		15-17	Black	802V560B
		18-19	Black	802V580B
Pocket connector top + bottom: POVH 10 mm for 0-6 mm gap				
POVH Pocket connector height				
Consisting of:				
3a	2 x	Front pocket connector		
3b	2 x	Rear pocket connector		
Pocket connector set				
4	Application without plinth			
		Pocket side thickness (mm)	Colour	Left Right
		15-17	Black	802V660B.L1 802V660B.R1
		18-19	Black	802V680B.L1 802V680B.R1
Top pocket connector: POVH 10 mm for 0-6 mm gap				
Bottom pocket connector: POVH 3 mm for gap from 7-13 mm				
POVH Pocket connector height				
Consisting of:				
4a	2 x	Front pocket connector		
4b	2 x	Rear pocket connector		
Pocket connector set				
5	Worktop-mounted cabinet application			
		Pocket side thickness (mm)	Colour	Left Right
		15-17	Black	802V760B.L3 802V760B.R3
		18-19	Black	802V780B.L3 802V780B.R3
Top pocket connector: POVH 10 mm for 0-6 mm gap				
Bottom pocket connector: POVH 3 mm for gap from 3-6 mm				
POVH Pocket connector height				
Consisting of:				
5a	2 x	Front pocket connector		
5b	2 x	Rear pocket connector		
Track set				
6	LWA2 double door (mm)			
		LWA2 double door (mm)	Colour	Left Right
		1050	Black anodised	802L1050DL3 802L1050DR3
		1200	Black anodised	802L1200DL3 802L1200DR3
		1250	Black anodised	802L1250DL3 802L1250DR3
		1350	Black anodised	802L1350DL3 802L1350DR3
Track can be shortened to any length.				
LWA2 Internal width within the application, double door				
Consisting of:				
6a	1 x	Track		
6b	1 x	Roller carriage		
6c	1 x	Roller carriage transporter		
6d	2 x	Mounting for track cover panels		
6e	1 x	Catch plate, black		
6f	2 x	Spacer		

Double door ordering information

8 Assembly set for a single door and double door combined			
LWA1 single door (mm)		Left	Right
600		802M6003.L3	802M6003.R3
700		802M7003.L3	802M7003.R3
800		802M8003.L3	802M8003.R3

Track extension can be shortened to any length.

LWA1 Internal width within the application, single door

Consisting of:

6d	1 x	Mounting for track cover panel
6f	1 x	Spacer
7a	1 x	Track fixing
7b	1 x	Cover for track fixing
7c	2 x	Pin for track fixing
8a	1 x	Track extension
8d	1 x	Track connection
8e	1 x	Cover for track connection
8f	1 x	Support angle for depth adjustment
8i	1 x	Inter-door support (right + left)

Z Accessories		
Inner door support incl. tip-assist		
	Length of support: 218 mm	802ZA030
	Length of support: 350 mm	802ZA031
For additional support on the worktop area, plinth front, cabinet, etc.		
Scuff guard		
	For front thicknesses starting from 23 mm	802ZA00S
	For front thicknesses less than 23 mm, the scuff guard can be used as additional front protection	
Consisting of:		
3 x	External pocket side scuff guard	
2 x	Internal pocket side scuff guard	

Double door ordering information

Z Accessories		
Screws		
	6 x 14.5 mm system screws, nickel plated	661.1450.HG
Pocket connector		
	Rear pocket connector, pocket connector height (POVH) 10 mm	802V5002
Additional pocket connector for set-back plinth leg		
EXPANDO T – for thin fronts		
	EXPANDO T – single	70T4532T
EXPANDO T suitable for thin fronts – see page 81		
For front thicknesses less than 18 mm, we recommend a trial application		
Screws are not included in the scope of delivery		

Single door ordering information

1	Pocket profile set with TIP-ON			
	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right
	450	550	801P450E.L3	801P450E.R3
	500	600	801P500E.L3	801P500E.R3
	600	700	801P600E.L3	801P600E.R3
	700	800	801P700E.L3	801P700E.R3
	800	900	801P800E.L3	801P800E.R3

* Specification without pocket back. A back construction with a thickness of at least 3 mm is required.

Pocket profiles and TIP-ON unit pocket can be shortened to any nominal length.

Consisting of:

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1d	1 x	TIP-ON unit pocket
1e	5 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip
1h	1 x	BLUMATIC unit
1i	2 x	Door stabiliser: runner profile incl. end cap, black anodised

2 Hinge bracket set

	Pocket height (mm)	Left	Right
	1142-1356	801T1140.L3	801T1140.R3
	1357-1506	801T1350.L3	801T1350.R3
	1507-1656	801T1500.L3	801T1500.R3
	1657-1806	801T1650.L3	801T1650.R3
	1807-1956	801T1800.L3	801T1800.R3
	1957-2106	801T1950.L3	801T1950.R3
	2107-2256	801T2100.L3	801T2100.R3
	2257-2406	801T2250.L3	801T2250.R3
	2407-2556	801T2400.L3	801T2400.R3
	2557-2706	801T2550.L3	801T2550.R3
	2707-2856	801T2700.L3	801T2700.R3
	2857-2999	801T2850.L3	801T2850.R3

Cover strips must be shortened to the required length

Consisting of:

2a	1 x	Hinge strip, black
2f	1 x	Hinge bracket
2g	1 x	TIP-ON spacer
2h	1 x	TIP-ON incl. catch plate, black
2i	1 x	Pocket cover strip, black anodised
2l	3-5 x	Mountings for pocket cover strip
-	21 x	System screws for 1i, 2a, 2g and 8i, 6 x 14.5 mm, black


Single door ordering information



Pocket connector set				
3	Application with plinth			
	Pocket side thickness (mm)	15-19	Colour	Black 801V505B
Pocket connector top + bottom: POVH 10 mm for 0-6 mm gap				
POVH Pocket connector height				
Consisting of:				
3a	2 x	Front pocket connector		
3b	2 x	Rear pocket connector		
Pocket connector set				
4	Application without plinth			
	Pocket side thickness (mm)	15-19	Colour	Left 801V605B.L1 Right 801V605B.R1
Top pocket connector: POVH 10 mm for 0-6 mm gap				
Bottom pocket connector: POVH 3 mm for gap from 7-13 mm				
POVH Pocket connector height				
Consisting of:				
4a	2 x	Front pocket connector		
4b	2 x	Rear pocket connector		
Pocket connector set				
5	Worktop-mounted cabinet application			
	Pocket side thickness (mm)	15-19	Colour	Left 801V705B.L3 Right 801V705B.R3
Top pocket connector: POVH 10 mm for 0-6 mm gap				
Bottom pocket connector: POVH 3 mm for gap from 3-6 mm				
POVH Pocket connector height				
Consisting of:				
5a	2 x	Front pocket connector		
5b	2 x	Rear pocket connector		

Single door ordering information

Z	Accessories
Scuff guard	
	<p>For front thicknesses starting from 23 mm</p> <p>For front thicknesses less than 23 mm, the scuff guard can be used as additional front protection</p>
Consisting of:	
3 x	External pocket side scuff guard
Screws	
	6 x 14.5 mm system screws, nickel plated
Pocket connector	
	<p>Rear pocket connector, pocket connector height (POVH) 10 mm</p> <p>Additional pocket connector for set-back plinth leg</p>
EXPANDO T – for thin fronts	
	EXPANDO T – single
EXPANDO T suitable for thin fronts – see page 81	
For front thicknesses less than 18 mm, we recommend a trial application	
Screws are not included in the scope of delivery	

Planning



Planning**Minimum side gap****Pocket to pocket/adjacent cabinet****Pocket to wall/decor panel****FD (mm)**


18–20
20.1–23
23.1–26

Min. Fs (mm)

2
2.5
3

FD Front thickness

Fs Side gap

Installation height, front height**Application with plinth**

$FH = POH - Fo - Fu$

$EH = POH + POVH$ top and bottom

$POVH$ 10 mm: gap 0–6 mm

- Take into account that the pocket must be tilted during installation.
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- The pocket connector height must be taken into account during planning
- Minimum plinth height 80 mm

EH Installation height




Fo Top gap

Fu Bottom gap

FH Front height

POH Pocket height

POVH Pocket connector height

Application with set-back plinth**Additional rear pocket connector****REVEGO uno****REVEGO duo****Planning****Installation height, front height****Application without plinth**

$FH = POH - Fo - Fu$

$EH = POH + POVH$ top and bottom

$POVH$ top 10 mm: gap 0–6 mm

$POVH$ bottom 3 mm: gap from 7–13 mm

- Take into account that the pocket must be tilted during installation.
- Minimum distance from the bottom front edge to the floor or next element below is 10 mm
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- The pocket connector height must be taken into account during planning

EH Installation height


Fo Top gap

Fu Bottom gap

FH Front height

POH Pocket height

POVH Pocket connector height

Installation height, front height**Worktop-mounted cabinet application**

$FH = POH - Fo - Fu$

$EH = POH + POVH$ top and bottom

$POVH$ top 10 mm: gap 0–6 mm

$POVH$ bottom 3 mm: gap from 3–6 mm

- Take into account that the pocket must be tilted during installation.
- The minimum distance between the front and the next element below with a flush front (e.g. worktop is not visible) is 3 mm
- The minimum distance between the front and the next element below with a protruding element (e.g. worktop is visible) is 6 mm
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- A trial application is recommended in the edge areas
- The pocket connector height must be taken into account during planning
- The distance between the front and the next element above and below is made up of Fu or Fo + POVH

EH Installation height

Fo Top gap

Fu Bottom gap

FH Front height

POH Pocket height

POVH Pocket connector height

* If the distance between the front and the next element below is < 6 mm, the pocket connector must be embedded in the worktop

Planning**Max. front weights for worktop-mounted cabinets in kg per front**


Front height FH (mm)	Front width FB (mm)						
	450	500	550	600	650	700	750
1130 - 1349	22	20	18	16	15	14	13
1350-1499	23	21	19	18	17	16	15
1500-1649	25	23	21	19	18	17	16
1650-1799	27	25	23	21	20	19	18

Note**REVEGO uno:**

- The max. front width when planning a worktop-mounted cabinet is 750 mm
- The max. pocket height when planning a worktop-mounted cabinet is 1806 mm


REVEGO duo:

- The max. pocket height when planning a worktop-mounted cabinet is 1806 mm

Inter-door support


- Supports a single door against a double door, two single doors against each other or two double doors against each other

P Pocket

Inner door support incl. tip-assist

- Support on the worktop area, plinth front, cabinet, etc.
- Distance from internal cabinetry: 70-218/350 mm
- Assembly height of the door support ideally as far down as possible, however up to a maximum height of 1000 mm from the front bottom edge

P Pocket

Planning**Track installation dimension**

LBH = 83 mm

LBD = 15-19 mm
(the spacer must be used ≤ 17 mm)

LTF = 17 mm

LA = 100 mm

LV = LA + ZBD (≥ 15 mm)

- We recommend using a cross member to stabilise the fixed shelf.
- Minimum distance to front edge of internal pocket side = 170 mm
- A solid connection between the fixed shelf and the pocket with connector fittings is recommended for an attractive gap layout
- No mounting of add-on parts directly on the track

FD Front thickness

LA Track cut-out

LV Track installation


LBD Track cover panel thickness

LBH Track cover panel height

LTF Track gap

PORS Pocket back cut

ZBD Fixed shelf thickness

Internal height and internal depth within the application

LHA = POH - LV

LTA = POT - 70 mm

- The internal height/internal depth within the application determines the maximum height/depth available for the internal cabinetry.

LHA Internal height within the application

LTA Internal depth within the application

LV Track installation

POH Pocket height

POT Pocket depth


REVEGO duo + duo – double door right and double door left



Space requirement

Installation dimensions (mm)	Installation width EB	Installation height EH	Installation depth ET
	1800–3000	1155–3012	from 573
Internal dimensions within the application (mm)	Internal width within the application LWA	Internal height within the application LHA	Internal depth within the application LTA
	up to 2700	up to 2884	from 483
Pocket dimensions (mm)	Pocket width POB	Pocket height POH	Pocket depth POT
	150	1142–2999	from 553
Front dimensions (mm)	Front width FB	Front height FH	Front thickness FD
	442–748	1130–2980	18–26
Front weight FG	up to 35 kg per front		

Overview



Fittings selection made easy

It is easy to work out the fittings and drilling positions you need using the Product Configurator.

With every product configuration, you will receive manufacturing drawings, cutting lists for wooden parts and fittings, 3D CAD data for your design software, as well as CAM programs including drilling information for direct machining on your CNC machine, in addition to the checked parts list.

Enter the web code in the Product Configurator, click on the short URL or scan the QR code. Don't have login information for digital services yet? Register here and get access free of charge.

Web code




Product Configurator
www.blum.com/rev12



Assembly and adjustment
www.blum.com/rev6

Component overview

Pocket




Consisting of:

- 1a Top pocket profile
- 1b Bottom pocket profile
- 1c Roller profile
- 1d TIP-ON unit pocket
- 1e Fixing clips
- 1f BLUMOTION unit pocket
- 1g Attachment for pocket cover strip
- 2f Hinge bracket
- 2i Pocket cover strip
- 2l Mounting for pocket cover strip
- 2m Pocket cover strip support
- 3a/4a/5a Front pocket connector
- 3b/4b/5b Rear pocket connector
- Z Scuff guard
- POAS External pocket side
- POIS Internal pocket side
- PORW Pocket back

Component overview

Front




Consisting of:

2a	Hinge strip
2b	Centre hinge
2c	Roller carriage hinge
2d	TIP-ON unit door
2e	Support for door cover strip
2j	Door cover strip
2k	Mounting for door cover strip
8i	Inter-door support
Z	Inner door support incl. tip-assist

A We recommend at least one alignment fitting per front with a maximum installation height of 20 mm.
The space available between the pair of folding fronts is 20 mm.

Component overview

Track



Consisting of:

2i	Pocket cover strip incl. mounting
6a	Track
6b	Roller carriage
6c	Roller carriage transporter
6d	Mounting for track cover panels
6e	Catch plate
6f	Spacer
9a	Track connection
9b	Cover for track connection
9c	Support angle for depth adjustment
LTB	Track cover panel
ZB	Fixed shelf

Ordering information

1	Pocket profile set with TIP-ON			
	Nominal length NL (mm)	Min. pocket depth POT* (mm)	Left	Right
450	550		802P450D.L3	802P450D.R3
525	625		802P525D.L3	802P525D.R3
600	700		802P600D.L3	802P600D.R3
675	775		802P675D.L3	802P675D.R3
750	850		802P750D.L3	802P750D.R3

* Specification without pocket back. A back construction with a thickness of at least 3 mm is required.

Pocket and roller profiles as well as TIP-ON unit pocket can be shortened to any nominal length.

Consisting of:

1a	1 x	Top pocket profile
1b	1 x	Bottom pocket profile
1c	1 x	Roller profile
1d	1 x	TIP-ON unit pocket
1e	6 x	Fixing clips
1f	1 x	BLUMOTION unit pocket
1g	5 x	Attachment for pocket cover strip

Order set for each double door, 1x left and 1x right

2	Hinge bracket set with TIP-ON			
	Pocket height (mm)	Left	Right	
	1142–1356	802T1140.L3	802T1140.R3	
	1357–1506	802T1350.L3	802T1350.R3	
	1507–1656	802T1500.L3	802T1500.R3	
	1657–1806	802T1650.L3	802T1650.R3	
	1807–1956	802T1800.L3	802T1800.R3	
	1957–2106	802T1950.L3	802T1950.R3	
	2107–2256	802T2100.L3	802T2100.R3	
	2257–2406	802T2250.L3	802T2250.R3	
	2407–2556	802T2400.L3	802T2400.R3	
	2557–2706	802T2550.L3	802T2550.R3	
	2707–2856	802T2700.L3	802T2700.R3	
	2857–2999	802T2850.L3	802T2850.R3	

Cover strips must be shortened to the required length

Consisting of:

2a	1 x	Hinge strip
2b	5 x	Centre hinge
2c	1 x	Roller carriage hinge
2d	1 x	TIP-ON unit door
2e	1 x	Support for door cover strip
2f	1 x	Hinge bracket
2i	1 x	Pocket cover strip, black anodised
2j	1 x	Door cover strip, black anodised
2k	4 x	Mounting for door cover strip
2l	2–5 x	Mountings for pocket cover strip
2m	1 x	Pocket cover strip support

Order set for each double door, 1x left and 1x right

Ordering information

3	Pocket connector set			
	Application with plinth		Colour	
		Pocket side thickness (mm)	15–17	Black
			18–19	Black

Pocket connector top + bottom: POVH 10 mm for 0–6 mm gap

POVH Pocket connector height

Consisting of:

3a	2 x	Front pocket connector
3b	2 x	Rear pocket connector

Order 1x per double door

4	Pocket connector set			
	Application without plinth		Colour	
		Pocket side thickness (mm)	15–17	Black
			18–19	Black

Top pocket connector: POVH 10 mm for 0–6 mm gap

Bottom pocket connector: POVH 3 mm for gap from 7–13 mm

POVH Pocket connector height

Consisting of:

4a	2 x	Front pocket connector
4b	2 x	Rear pocket connector

Order set for each double door, 1x left and 1x right

5	Pocket connector set			
	Worktop-mounted cabinet application		Colour	
		Pocket side thickness (mm)	15–17	Black
			18–19	Black

Top pocket connector: POVH 10 mm for 0–6 mm gap

Bottom pocket connector: POVH 3 mm for gap from 3–6 mm

POVH Pocket connector height

Consisting of:

5a	2 x	Front pocket connector
5b	2 x	Rear pocket connector

Order set for each double door, 1x left and 1x right

Ordering information

6	Track set			
	LWA double door (mm)	Colour	Left	Right
	1050	Black anodised	802L1050DL3	802L1050DR3
	1200	Black anodised	802L1200DL3	802L1200DR3
	1250	Black anodised	802L1250DL3	802L1250DR3
	1350	Black anodised	802L1350DL3	802L1350DR3

Track can be shortened to any length.

LWA Internal width within the application

Consisting of:

6a	1 x	Track
6b	1 x	Roller carriage
6c	1 x	Roller carriage transporter
6d	2 x	Mounting for track cover panels
6e	1 x	Catch plate, black
6f	2 x	Spacer


Order set for each double door, 1x left and 1x right

9	Assembly set for two double doors combined		
	Colour		
	Black		
Consisting of:			
9a	1 x	Track connection	802M0004.03
9b	1 x	Cover for track connection	
9c	1 x	Support angle for depth adjustment	
9e	1 x	Inter-door support (right + left)	

Ordering information

Z	Accessories
	Inner door support incl. tip-assist
	 Length of support: 218 mm 802ZA030
	 Length of support: 350 mm 802ZA031
	For additional support on the worktop area, plinth front, cabinet, etc.
	Scuff guard
	 For front thicknesses starting from 23 mm 802ZA00S
	For front thicknesses less than 23 mm, the scuff guard can be used as additional front protection
	Consisting of:
3 x	External pocket side scuff guard
2 x	Internal pocket side scuff guard
	Screws
	 6 x 14.5 mm system screws, nickel plated 661.1450.HG
	Pocket connector
	 Rear pocket connector, pocket connector height (POVH) 10 mm 802V5002
	Additional pocket connector for set-back plinth leg
	EXPANDO T – for thin fronts
	 EXPANDO T – single 70T4532T
	EXPANDO T suitable for thin fronts – see page 81
	For front thicknesses less than 18 mm, we recommend a trial application
	Screws are not included in the scope of delivery

Planning



Installation width/internal width within the application

$$EB = 2 \times LWA2 + 2 \times POB (150 + 150 \text{ mm})$$

Front width/front protrusion

$$FB = (EB - Fsl - 3 \times Fsm - Fsr) : 4 \text{ (fronts)}$$

$$Fsl/Fsr = 1.0-4.0 \text{ mm; } Fsm = 2.0-8.0 \text{ mm}$$

$$\text{Max. NL} = FB + 8 \text{ mm}$$

$$FU = FB - NL + 15 \text{ mm} \\ (\text{min. } FU = 7 \text{ mm})$$

Installation depth/pocket depth

$$ET = POT + FS (2 \text{ mm}) + FD$$

$$FD = 18-26 \text{ mm}$$


$$\text{Min. POT} = NL + POTV (\geq 100 \text{ mm}) + PORW (\geq 3 \text{ mm})$$

$$POSD = 15-19 \text{ mm}$$


- By cutting the profiles to size, the front protrusion (FU) can be customised.
- To ensure optimum functionality, the fronts are at a slight angle inside the pocket.
- The internal width within the application determines the maximum width available for the internal cabinetry.
- For front thicknesses (FD) less than 18 mm (possible depending on material/stability), we recommend a trial application.

Minimum side gap

Pocket to pocket/adjacent cabinet



Pocket to wall/decor panel



FD (mm) Min. Fs (mm)


18-20	2
20.1-23	2.5
23.1-26	3

FD Front thickness
Fs Side gap

Planning

Installation height, front height

Application with plinth



$$FH = POH - Fo - Fu$$

$$EH = POH + POVH \text{ top and bottom}$$

$$POVH 10 \text{ mm: gap } 0-6 \text{ mm}$$

- Take into account that the pocket must be tilted during installation.
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- The pocket connector height must be taken into account during planning
- Minimum plinth height 80 mm

$$EH \text{ Installation height}$$

$$Fo \text{ Top gap}$$

$$Fu \text{ Bottom gap}$$


$$FH \text{ Front height}$$

$$POH \text{ Pocket height}$$

$$POVH \text{ Pocket connector height}$$


Application with set-back plinth

Additional rear pocket connector



Installation height, front height

Application without plinth



$$FH = POH - Fo - Fu$$

$$EH = POH + POVH \text{ top and bottom}$$

$$POVH top 10 \text{ mm: gap } 0-6 \text{ mm}$$

$$POVH bottom 3 \text{ mm: gap from } 7-13 \text{ mm}$$

- Take into account that the pocket must be tilted during installation.
- Minimum distance from the bottom front edge to the floor or next element below is 10 mm
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- The pocket connector height must be taken into account during planning

$$EH \text{ Installation height}$$

$$Fo \text{ Top gap}$$

$$Fu \text{ Bottom gap}$$

$$FH \text{ Front height}$$


$$POH \text{ Pocket height}$$

$$POVH \text{ Pocket connector height}$$

Planning

Installation height, front height

Worktop-mounted cabinet application



FH = POH - Fo - Fu

EH = POH + POVH top and bottom

POVH top 10 mm: gap 0-6 mm

POVH bottom 3 mm: gap from 3-6 mm

- Take into account that the pocket must be tilted during installation.
- The minimum distance between the front and the next element below with a flush front (e.g. worktop is not visible) is 3 mm
- The minimum distance between the front and the next element below with a protruding element (e.g. worktop is visible) is 6 mm
- Minimum distance to the next movable element above 3 mm, for non-movable elements a front insertion space of 6 mm must be taken into account
- A trial application is recommended in the edge areas
- The pocket connector height must be taken into account during planning
- The distance between the front and the next element above and below is made up of Fu or Fo + POVH

EH Installation height

Fo Top gap

Fu Bottom gap

FH Front height

POH Pocket height

POVH Pocket connector height

* If the distance between the front and the next element below is < 6 mm, the pocket connector must be embedded in the worktop

Max. front weights for worktop-mounted cabinets in kg per front


Front height FH (mm)	Front width FB (mm)						
	450	500	550	600	650	700	750
1130 - 1349	22	20	18	16	15	14	13
1350-1499	23	21	19	18	17	16	15
1500-1649	25	23	21	19	18	17	16
1650-1799	27	25	23	21	20	19	18

Note

- The max. pocket height when planning a worktop-mounted cabinet is 1806 mm

Planning


Inner door support



- Support on the worktop area, plinth front, cabinet, etc.
- Distance from internal cabinetry: 70-218/350 mm
- Assembly height of the door support ideally as far down as possible, however up to a maximum height of 1000 mm from the front bottom edge

P Pocket

Inter-door support



- Supports a single door against a double door, two single doors against each other or two double doors against each other

P Pocket


Track installation dimension

LBH = 83 mm

LBD = 15-19 mm
(the spacer must be used ≤ 17 mm)

LTF = 17 mm

LA = 100 mm

LV = LA + ZBD (≥ 15 mm)

- We recommend using a cross member to stabilise the fixed shelf.
- Minimum distance to front edge of internal pocket side = 170 mm
- A solid connection between the fixed shelf and the pocket with connector fittings is recommended for an attractive gap layout
- No mounting of add-on parts directly on the track

FD Front thickness

LA Track cut-out

LV Track installation

LBD Track cover panel thickness


LBH Track cover panel height

LTF Track gap

PORS Pocket back cut

ZBD Fixed shelf thickness

Internal height and internal depth within the application



LHA = POH - LV

LTA = POT - 70 mm

- The internal height/internal depth within the application determines the maximum height/depth available for the internal cabinetry


LHA Internal height within the application

LTA Internal depth within the application

LV Track installation

POH Pocket height

POT Pocket depth



Product Configurator

Obtain the exact calculation for assembling the cut-to-size profiles quickly and efficiently using the Product Configurator. The configurator calculates all the dimensions for each configuration and also outputs them as drawings.




www.blum.com/rev1

Calculations and assembly of the profiles

REVEGO duo | Double door

Pocket cover strip, door cover strip




FH	Front height
POH	Pocket height
2i	Pocket cover strip
2j	Door cover strip

Calculations and assembly of the profiles

REVEGO duo | Double door

Roller profile, pocket profile, TIP-ON unit pocket



NL = POT - POTV - PORW

#P1	1a	Top pocket profile
#P2	1c	Roller profile
#P3	1d	TIP-ON unit pocket
#P5	1b	Bottom pocket profile

NL Nominal length

POT Pocket depth

PORW Pocket back

POTV Pocket depth loss


Note

- Pocket and roller profiles as well as TIP-ON unit pocket must not be damaged during cutting to size.
- Pocket and roller profiles as well as TIP-ON unit pocket must be cleaned to remove any dirt and deburred before installation.

Calculations and assembly of the profiles

REVEGO uno | Single door


Pocket cover strip



Calculations and assembly of the profiles

REVEGO uno | Single door

Pocket profile, TIP-ON unit pocket, door stabiliser



NL Nominal length

POT Pocket depth

PORW Pocket back

POTV Pocket depth loss


Note

- Pocket profiles, TIP-ON unit pocket and door stabiliser must not be damaged during cutting to size.
- Pocket profiles, TIP-ON unit pocket and door stabiliser must be cleaned to remove any dirt and deburred before installation.

Calculations and assembly of the profiles

REVEGO duo | Double door

Track, track extension



Application	X	Y
REVEGO duo	–	LWA - 12 mm
REVEGO uno + duo	LWA1 - 58 mm	LWA2 - 12 mm
REVEGO duo + duo	–	LWA2 - 12 mm
LWA	Internal width within the application	
LWA1	Internal width within the application, single door	
LWA2	Internal width within the application, double door	
6a	Track	
8a	Track extension	

EXPANDO T




- EXPANDO T – fixing system
- Thin fronts measuring 8 mm or more
- Different front materials

EXPANDO T – single

Colour	Material	
Dark grey	Nylon/steel	70T4532T

Drilling depth | Screw selection – EXPANDO T



Screws with M4 thread have to be used for EXPANDO T single

Select the lowest possible drilling depth to suit the screw length when using the single dowel

BT Drilling depth


ES Screw penetration depth

ES min. = 4 mm

ES max. = BT - 0.5 mm

* Stone and ceramic +0.2/-0.1 mm

Assembly – EXPANDO T



Area of application and assembly recommendation

EXPANDO T is suitable for fixing Blum fittings to thin cabinet fronts of all types of materials. Front materials can be just 8 mm thick or more, provided they are sufficiently stable and strong.

A trial application is recommended.

Nm Minimum tightening torque

Limitation of liability

Blum accepts no liability for the use of EXPANDO T in combination with materials not listed or fittings from other manufacturers. It is recommended that assembly be carried out by an experienced furniture manufacturer.

Materials tested by Blum	Nm
Chipboard (transverse tensile strength > 0.4 N/mm ²)	1.5
MDF (transverse tensile strength > 0.6 N/mm ²)	1.5
HDF	2
HPL	2
Mineral composites	2

Front weight

Max. 35 kg per front




Find more information on assembly and adjustment of EXPANDO T at
www.blum.com/rev13

Gauge set for REVEGO pocket connector


- Drilling template for horizontal drillings of REVEGO pocket connectors on the pocket side wall
- Material: nylon/steel/aluminium

Ordering information


STL.8000.01

Internal testing and inspection regulations**Durability**


40,000 opening and closing cycles.

Abuse test

Horizontal load test to ensure that system will withstand misuse

Slam open/slam shut test

To simulate overload when opening and closing and ensure that the fronts do not detach from fittings.

Corrosion testing

Based on DIN EN ISO 9227 and DIN EN ISO 6270-2 for simulating corrosion influences.

Blum Showrooms
Sydney (Head Office)
10 Blackbird Close
Len Waters Estate NSW 2171
Ph: 02 9612 5400

Adelaide
179 Railway Terrace
Mile End SA 5031
Ph: 08 8118 6070

Brisbane
6/39-45 Compton Road
Underwood QLD 4119
Ph: 07 3135 9490

Melbourne
245 Ferntree Gully Road
Mount Waverley VIC 3149
Ph: 03 9982 1720

Perth
3/425 Scarborough Beach Road
Osborne Park WA 6017
Ph: 08 6467 0110



Blum Australia Pty Ltd
PO BOX 1615, Green Valley,
NSW, 2168, Australia
Toll Free: 1800 179 186
E-mail: info.au@blum.com
blum.com

